


ASSEMBLY INSTRUCTIONS
8931R-TB


PART LIST

DO NOT FULLY TIGHTEN SCREWS AND NUTS UNTIL THE ENTIRE ITEM IS COMPLETELY ASSEMBLED


(A) Top Assembly - (1pc)



(B) Extension Leaf - (1pc)



(C) Legs - (4pcs)



HARDWARE LIST

Nut



Spring Washer



(1) Ø5/16" x 6mm
(8pcs)



Flat Washer

(2) Ø5/16" x 13mm
(8pcs)




Wrench


(3) Ø5/16" x 19mm
(8pcs)

(4) Ø5/16" x 90mm
(1pc)


STEP 1



STEP 2



STEP 3



COMPLETE.